



| | spare part no |
|--------------------------------|---------------|
| ① FUEL PUMP, FC 1 | 367501 |
| ③ CONTROL UNIT, XP350 | 361064 |
| ⑤ THERMO ELEMENT | 362601 |
| ⑦ GASKET FOR T4 THERMO ELEMENT | 364015 |
| ⑨ OVERHEAT THERMOSTAT | 362415 |
| ⑪ BURNER CYLINDER COMPLETE | 369024 |
| ⑬ FUEL PIPE | 367306 |
| ⑮ FUSE 15 A | 362110 |
| ○ | |

| | spare part no |
|---------------------------|---------------|
| ② COMBUSTION BLOWER | 365312 |
| ④ HOT PLATE INDICATOR LED | 361020 |
| ⑥ GLOW PLUG | 362502 |
| ⑧ RADIATION ELEMENT | 369007 |
| ⑩ BOTTOM MAT, Ø 85 MM | 364023 |
| ⑫ GASKET FOR GLOW PLUG | 364110 |
| ⑭ FUSE 5 A | 362108 |
| ○ | |
| ○ | |